



DBManager

User Manual

Version 1.25



INDEX

1	INTRODUCTION	3
2	INSTALLATION	3
3	SOFTWARE ACTIVATION	6
	<i>Automatic Registration</i>	<i>6</i>
	<i>Activation by E-mail</i>	<i>8</i>
	<i>Activation by phone call</i>	<i>9</i>
4	SCALE CONFIGURATION.....	10
	<i>Automatic search</i>	<i>11</i>
	<i>Manual search.....</i>	<i>12</i>
5	ARCHIVES COMPILATION	15
	WARRANTY AND USER LICENSE	17
	<i>Declaration of responsibility.....</i>	<i>17</i>


1 INTRODUCTION

DBManager.NET allow to manage and view databases on 3590 instruments by PC with an user friendly interface.


It also possible to select the desired language.

2 INSTALLATION


To install the program follow this procedure:




Run Setup as administrator




Select your language and click “OK”



Read Warranty and user licence and click “I Agree”




Choose the installation path and click "Install"



When the installation is completed click "Close"


3 SOFTWARE ACTIVATION

When software is not activated, it starts with the following screen:



After 10 seconds, you can use it in DEMO mode or you can Register it.

Press **Register Now** key and select how to activate it




1. **Automatic mode:** it is the easiest method but it requires the use of the internet during the activation. If Internet communication is disabled, you must enable it only for a few minutes in order to activate the software and then you can turn it off.
2. **Mode by E-mail:** it is a manual method. First, please, withdraw the code provided or by registered mail from the software manufacturer.
3. **Mode by Phone:** it is a manual method. First, please, withdraw the code provided or by registered mail from the software manufacturer.


Automatic Registration

Connect the PC to Internet

1. Press **Automatic** key
2. Enter the activation code provided



3. Now, the activation procedure continues automatically



4. Once the registration end successfully, close this screen to end the procedure.
Now the program is ready to work.




If you have not an internet connection, you can choose one of the other two activation modes after revoked the provided code by the software manufacturer

Activation by E-mail


Click on **E-mail** key and you need to:

1. Generate the license requested file "LicenseRequest"
2. Send it via e-mail
3. Wait for the complete file license
4. Import the complete file license received

The PC asks if you have an activation code. If not, press **No** key




The PC creates the file "*Licence Request*" to be saved and forwarded to the manufacturer by e-mail indicating the name of the company and the software to be registered




Soon, the producer you will send by email a file **DiniargeoLicence.Lic** indicating the activation code.

Repeat the procedure and when the PC asks if you have an activation code, press **Yes** key




A window appears with a grid of 18 numbers to fill.



Press **Import** key and import the code that came from the manufacturer and which has been saved on your PC.

A series of numbers appear in the grid. Press **Register** key.



Activation is completed but the PC requests to restart the software.



Activation by phone call

If you wish to choose the phone mode, press **By phone** and call who provided to you the software





4 Scale configuration


To create a new scale database, go to Tools on the top left corner and click





Select your language and click




A window appears and it allows to set the connection parameters



If you choose  it auto scan the serial ports to find connected scales(recommend). If you have a network scale go to the next step.

If you choose  you need to insert the serial or TCP-IP parameters manually

Automatic search



Select your scale and click






Manual search


Choose if you connect the scale via COM (serial port) or TCP – IP (network)


Insert the communication parameters and click  Test Connection to test the connection.

If a scale has found a message appears, if not, check if the parameters are correct or if the scale is connected correctly to PC.


When you have done click



Compile metrological scale parameters like number of connected scale, capacity, division, decimals and click 



DBManager starts to read archive structure, it is possible to change the labels of Archives clicking on the label and Enable/Disable fields.





Select fields to show :

Articles data Tare_dtb In

Articles data

☒ Description_1

☒ Description_2

☐ Description_3

☒ Linked_tare

To proceed click 

The software start to read all archives, wait until it ends

5 Archives compilation

DBManager 1.26

Tools Help

EGT-AF01

EGT-AF01

Articles Tare Texts Customers SN: 200123456

	ID	Description 1	Description 2	Description 3	Linked tare	Linked customer	Gross total	Tare total	Weighs_to	Setpoint 1	Setpoint 2	Setpoint 3
	1				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	2				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	3				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	4				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	5				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	6				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	7				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	8				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	9				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	10				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	11				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	12				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	13				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	14				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	15				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	16				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	17				0	0	0,000	0,000	0,000	0,000	0,000	0,000
	18				0	0	0,000	0,000	0,000	0,000	0,000	0,000

DINI ARCEO
Scales - Weighing systems

FULL Version


Legend:

- Modify the record
- View the record
- Send to the indicator the selected records
- Create a new record
- Delete selected records
- Refresh the window
- Modify archive labels
- Recive all archives from the indicator
- Send all records to the indicator
- Delete the scale on DBManager

To modify a record click on 

Articles data		Tare_d	
		ID	Descripti
		1	
		2	
		3	
		4	

A window will appears and it is possible to edit the descriptions



Then click on  to save it

Articles data		Tare_dtb		Input_texts		Customer_dtb	
		ID	Description	Description	Description	Li	ta
		1	Apple	Fruit		0	
		2				0	
		3				0	

Now the article is compiled, click on  to send it to the indicator

Warranty and user license

Ownership of the software

It is expressly forbidden to copy, modify, resell and/or distribute the software without the explicit consensus of Syntweb.

The products developed by Syntweb are of the exclusive ownership of Syntweb. Any reference to other firms and/or registered marks owned by other firms may be cited only for the purpose of plain reference.

Warranty

Syntweb guarantees that the software will work in substantial conformity with the analysis, manuals and the documents accompanying the product, for a period of 90 days from the date of purchase (for standard software) or from the date of testing (for special software): for this entire time period the customer will have to test the software in its entirety and communicate any inexactness to Syntweb who commits itself to supply all the necessary assistance in order to resolve any inexactness, functioning problem, or "bug" (expressly recognized as that) of the released software, in the shortest time possible.

Once 90 days have passed from the software release any modification or variation to the software must be regularly invoiced as an intervention of modification.

Syntweb does not guarantee the functioning of the software on machines that do not satisfy the specified requirements or on which are installed products by third parties who interfere directly or indirectly with the functioning of the software.

In case of installation, removal or replacement of any network device that modify the MAC address of the hardware on which the software has been installed, the software license will be invalidated and the software will stop to work.

If the software is installed on a virtual machine, the machine requires Internet connection. Should the machine fail to connect to Internet for more than 45 days the software will cease to work. Specific warning advice will inform the user of this event starting from the first day of lack of connection and then for the following 44 days. At the end of this period the software will stop to function until a new connection to Internet will be established.

Declaration of responsibility

In no event will Syntweb be liable for the damages (including, without limitations, the damage caused by loss of profits, interruption of the activities, loss of data, or other economic losses) deriving from the use of the software, even in the case that Syntweb has been advised of the possibility of such damages.